

Checking the Eco Information

Eco information indicates the result of calculating the paper saving ratio and the accumulated time during power saving based on the user's use conditions. This information will help you gain an understanding of the usage status of this machine.

1. Tap [Utility] - [Counter].

2. Tap [Eco Info].

The screenshot displays the 'Eco Info' screen. On the left, there is a 'Meter Count' section with the following data:

| Meter Count |
|--------------|
| Total 165 |
| Black 165 |
| Color 0 |


The main area shows a table of usage statistics for 'Serial Number : 1'. The table has columns for 'Copy', 'Print', 'Scan/Fax', and 'Other'. The 'Copy' tab is selected, and the table shows the following data:


| | Total | Large Size | Total (Copy + Print) |
|--------------|-------|------------|----------------------|
| Black | 133 | 0 | 133 |
| Full Color | 0 | 0 | 0 |
| Single Color | 0 | 0 | ----- |
| 2 Color | 0 | 0 | 0 |
| Total | 133 | 0 | ----- |


At the bottom of the screen, there are buttons for 'Print List' and 'Eco Info' (highlighted with a red box). The date and time '02/05/2015 07:28' are displayed at the bottom left, and a 'Close' button is at the bottom right.

The Eco Info screen is displayed.


Eco Info 1 Eco Info 2

Color Ratio % 0 

Duplex Print Ratio % 0 

Combine (Nin1) Print Ratio % 0 

Close



Contents of Eco Information

[Eco Info 1]

Indicates the rate of color print jobs or 2-sided print jobs for all print jobs or the rate of page combination for the number of scanned original pages. You can check the ratio of paper saved.



[Eco Info 2]

Indicates the accumulated monthly or hourly time during power-on, standby, power saving, or running. The display mode can be selected from the list or graph format.

The screenshot displays a user interface for 'Eco Info 2'. At the top, there are two tabs: 'Eco Info 1' and 'Eco Info 2'. Below the tabs, there are two buttons: 'Monthly' (highlighted) and 'Hourly'. To the right of these buttons are a heart icon and a menu icon. Below the buttons is a table with four columns: 'November', 'December', 'Last Month', and 'Current Month'. The table has four rows of data. A 'Close' button is located at the bottom right of the interface.

| | November | December | Last Month | Current Month |
|---------------------------------|----------|----------|------------|---------------|
| Power Connection Total Time (H) | 0.0 | 60.0 | 105.3 | 25.2 |
| Standby Mode Total Time (H) | 0.0 | 59.7 | 104.8 | 25.1 |
| Power Save Mode Total Time (H) | 0.0 | 0.0 | 0.0 | 0.0 |
| Operating Mode Total Time (H) | 0.0 | 0.4 | 0.5 | 0.0 |